



# Thermal Printer

Dirt causes misreads, print errors, and costly replacements

Print errors in your barcodes, labels, and receipts are a result of dirty print heads. Our thermal printer cleaning card is designed to remove the most stubborn and baked-on contaminants, keeping your images clear and your operations running smoothly.

- In one study, print heads lasted 3x longer with regular cleaning
- According to MIDCOM Data Technologies, the main cause of failures for thermal barcode printers is due to the print heads not being cleaned regularly

**“Waffletechnology® cleaning cards have been designed to quickly clean our printers better than any product available.”**

**Neil Edmonds,**  
Sr Marketing Manager,  
System Device Group, Epson America

**EPSON®**

## THE KIC DIFFERENCE

### WAFFLETECHNOLOGY®

Waffletechnology® incorporates flexible, raised platforms on their top and bottom surfaces that are spring-loaded, increasing the pressure applied to the internal components.

### Adhesive Remover

Our safe and effective formula breaks down the adhesive structure making it easy to remove and preventing it from reattaching.

## PREVENTATIVE CARE

Clean your Thermal Printer with every media roll change or at least once a month with a KIC cleaning card and adhesive remover swab or pen.



**Discover** the Benefits  
of Cleaning

CASE STUDY

**Who:**

A large online retailer in the UK

**Challenges:**

Reducing replacement costs on thermal printer parts

**What they did:**

Technicians cleaned 10 printers with thermal printer cleaning cards after every label change. The other 10 printers were not cleaned.

**Results:**

**\$425,000**

Saved per year.

Print heads lasted almost 3 times longer when they were cleaned. The technician estimated that he saved £250,000 (approx. \$425,000) per year on printer parts.

PRODUCTS



**Waffletechnology for Thermal Printers - 15 Count Box**

Remove stock from printer. Insert card into feed path. Close printer and pull card out.

Select card width to match width of thermal paper in device.

**2" card** PN: KW3-T26B15

**3" card** PN: KW3-T36B15

**4" card** PN: KW3-T46B15



**6" Cleaning Swabs with IPA - 50 Count Box**

Swipe swab across print head or interior surface.

PN: K2-S6T50

**6" Adhesive Remover Swabs - 50 Count Box**

Swipe swab across print head or interior surface. Allow for solution to penetrate adhesive build-up

PN: K2-S6T50AR



**Thermal Printer Cleaning Pens - 12 Count Box**

Swipe pen across print head or interior surface. Use scraping tool on print heads only.

PN: KT-PJCB12

**Adhesive Remover Pens - 12 Count Box**

Swipe pen across print head or interior surface. Allow for solution to penetrate adhesive build-up. Use scraping tool (on print head only) to remove completely.

PN: KT-PJCB12AR



**SheerDevice™ Wipes - 50 or 100 Count Box**

Use cleaning wipe on all surfaces, including keypads.

PN: K2-WDVCT50

PN: K2-WDVCT100